

Brand	Model	CNC Head Porting (£)	Taping (£)	Guides Fitted Calsibro (Set) (£)	Stainless S Valves (£)	Valve Seats (£)	Cams (£)	Clearance for Cams to turn (£)	Spring Base Machining For Correct fitted hieght (£)
ALFA ROMEO	156	850	100	240	448			100	300
ALFA ROMEO	16V	850	100	240	448			100	300
AUDI	1.8T (Big Valve)	1250	100	300	560			100	350
AUDI	1.8T (Standard Valve)	1250	100	300	560			100	350
AUDI	1.9 Tdi (PD)	650	100	120	224			-	200
AUDI	RS6 V10 (pair)	1500	200	600	1120			200	600
BMW	24v	1250	100	360	672			100	300
BMW	M3 2.5 litre DTM (E30)	1350	100	240	448			-	300
BMW	M3 V8 4000cc (Pair)	1400	200	480	896			200	400
BMW	M5 (V8)	1400	200	480	896			200	600
BMW	M5/M6 (V10) – Pair	1500	200	600	1120			200	400
BMW	Mini & Mini Cooper	850	100	240	448			100	300
BMW	S50	1250	100	360	672			-	300
BMW	S54	1250	100	360	672			-	300
BMW	S55	1250	100	360	672			-	300
BMW	V8	1400	200	360	896			200	400
CITROEN	1.6 C2 GT 16V	850	100	240	448			100	200
CITROEN	1.6 VTS 16V	850	100	240	448			100	200
DATSUN	240Z (Big valve)	750	100	180	336			-	200
DATSUN	260Z (Big valve)	750	100	180	336			-	200
FERRARI	V8 (Pair)	1400	200	360	896			200	400
FIAT	1.4l – 2.0l N/A and Turbo (Punto) 8V	650	100	120	224			100	200
FIAT	1.4l – 2.0l N/A and Turbo (Tipo) 8V	650	100	120	224			100	200
FORD	Cosworth (Big valve)	1250	100	240	648			100	300
FORD	Cosworth (Big valve) Normally Aspirated	1250	100	240	448			100	300

Brand	Model	CNC Head Porting (£)	Taping (£)	Guides Fitted Calsibro (Set) (£)	Stainless S Valves (£)	Valve Seats (£)	Cams (£)	Clearance for Cams to turn (£)	Spring Base Machining For Correct fitted hieght (£)
FORD	Cosworth (Std valve)	950	100	240	448			100	300
FORD	Crossflow(Alloy big valve version)	1095	100	120	224			-	200
FORD	CVH	495	100	120	224			-	150
FORD	CVH Turbo	495	100	120	224			-	150
FORD	Duratec 1.8 16V	850	100	240	448			100	200
FORD	Duratec 2.0 – 2.3 16V	850	100	240	448			100	200
FORD	Essex V6 (Pair)	1000	100	180	336			-	100
FORD	Focus RS	1050	100	240	448			100	200
FORD	Formula Ford(Regulation Standard)	950	100	180	224			-	100
FORD	Pinto (Big valve)	650	100	180	224			-	100
FORD	Puma 1.7	850	100	240	224			100	200
FORD	ST 2.5 Turbo)	1250	100	300	560			-	300
FORD	ST150"	850	100	240	448				300
FORD	ST170"	850	100	240	448				300
FORD	ST220"	1200	200	360	-				400
FORD	ST225"	-	-	-	-				-
FORD	Zetec 2.0 16V	850	100	240	448				300
GM	LS1 LS2 V8 (Pair)	1200	200	240	448				300
HEALEY	100-4	850	100	120	224				200
HOLDEN	LS1 LS2 V8 (Pair)	1200	200	240	448				300
JAGUAR	3000 V6	1200	200	360	672				300
LAMBORGHINI	V10 (Head Pair)	1500	200	600	1120				600
LOTUS	Lotus TC	1250	100	120	224				200
LOTUS	Lotus VHTP	1250	100	240	448				300
MAZDA	1.6	850	100	240	448				300
MERCEDES	24v	-	-	-	-				-

